

Genesys™ / ZUP - USB Solutions

The most cost effective way to connect a Genesys™ or ZUP to a computer via its USB interface is to use our GEN-232-9 cable (RJ45 to 9 pin serial D type connector) and a USB to serial adapter.

- Easy connection of Serial device through USB port
- A cost effective external solution is available from supplier Digitus
Part No. : DA-70156
Driver/ Manuals are available via Websites
- Compliant with USB 2.0 Standards
Supports RS-232 Serial Interface
- Supports Windows 7, Vista, XP, Mac OS X and Linux
- Part Nos.: USB- Adapter: ACC-GEN-337848
 Serial Cable: GEN-232-9

